


## DCDALCI, DCDALCI2 Isolated Interface

### Introduction

DCBM DALI line controllers provide RS232 data connections for DALI addressable lighting systems. To connect a DCBM controller to a DALI line, an isolating interface is required.

### Installation

The DCDALCI is in a specialised package and connects to the DCBM controller using a 9-pin DIN male connector. The DCDALCI2 is in a DIN rail package and connects to the new DIN rail DCBM controller with an RS485 patch cord.



DALI SCI

DCDALCI2

	DCDALCI	DCDALCI2
DCBM2-0808	x 2	not compatible
DCBM2-1602	x 2	not compatible
DCBM1-1608	not compatible	x 1
DCBM2-1608	not compatible	x 2



### Clipsal Australia Pty Ltd

A member of Schneider Electric

#### Head Office

33-37 Port Wakefield Road,  
Gepps Cross, South Australia 5094

#### Postal Address

PO Box 132  
Enfield Plaza, South Australia 5085

Website [www.dalicontrol.com](http://www.dalicontrol.com)

Contact your local Schneider Electric office for sales and technical support. [www.clipsal.com/trade/contact\\_us](http://www.clipsal.com/trade/contact_us)

You can find this data sheet and many others online in PDF format at:  
[www.dalicontrol.com](http://www.dalicontrol.com)

**clipsal.com**

Clipsal Australia Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© Clipsal Australia Pty Ltd

This material is copyright under Australian and international laws. Except as permitted under the relevant law, no part of this work may be reproduced by any process without prior written permission of and acknowledgement to Clipsal Australia Pty Ltd.